


Assembly Manual

for Polycarbonate Greenhouses

8 x 6 Greenhouse



Assembly Manual

for Polycarbonate Greenhouses

8 x 6 Greenhouse

Table of Contents

Introduction	1
General Advice	1
About This Manual	2
Maintenance	3
Parts List	4
Assembling of pre-fabricated Base	5
Two foundation options with pre-fabricated Base	6
Step 1: Assembling of Door	7
Step 2: Assembling of Roof Vent	9
Step 3: Assembling of Main Frame	11
Step 4: Assembling of Backwall	16
Step 5: Assembling of Front Wall	20
Step 6: Assembling of Roof Frames	25
Step 7: Securing of Frames	31
Step 8: Assembling of Middle Frame	36
Step 9: Assembling of Roof Vent Holder	38
Step 10: Assembling of Side Braces	40
Step 11: Assembling of Panels	42
Polycarbonate Panel Layout	43
Step 12: Assembling of Gutters and Caps	44
Securing the Greenhouse to the pre-fabricated Base	46

INTRODUCTION

CONGRATULATIONS

Congratulations on purchasing a Greenhouse. Please read the assembly manual and familiarise yourself with the parts and steps before assembling your Greenhouse.

NOTICE

It will take at least two adults about three hours to assemble the greenhouse. Do not assemble the greenhouse if tired or under the influence of alcohol, drugs or medication. Follow the manual step by step. Keep this manual for future reference.

IMPORTANT

The Greenhouse contains parts with sharp edges. Handle with care.

WEATHER

Do not assemble the greenhouse on a windy day.

USAGE

This is a hobby greenhouse. Use it as intended only. Do not allow children or pets to play in the greenhouse.

WORKING AREA

Keep bystanders, kids or pets out of the working area.

TOOLS

Safety Work Gloves, Safety Goggles, Spirit Level, Tape Measure, Step Ladders, Philips Screwdriver, 8mm M5 Wrench, 10mm M6 Wrench

GENERAL ADVICE

POLYCARBONATE SHEETS (Panels)

Polycarbonate sheets may scratch so be careful what you clean them with.

Do not use solvent cleaners to clean the sheets.

Polycarbonate sheets have sharp edges. Use safety work gloves while handling them.

Remove about 2 inches of films from all edges before installing.

Use the sheets as intended.

Remove all films after the construction is completed.

The UV-protected side of the sheet is covered with a layer of opal white film and must face the sun.

BASE

As per your choice, you may receive a greenhouse with or without a pre-fabricated base kit. Either way, this greenhouse must be secured to a firm base.

The Base must be level and square.

Before assembling the greenhouse, you must prepare a proper foundation. Two foundation options are provided in this manual. The concrete foundation option is recommended for a stronger installation.

SITE SELECTION

The greenhouse should be placed in an area that receives direct sunlight and gets shielded from wind.

The surface must be level.


ABOUT THIS MANUAL

LEGENDS

A Steps. Follow the steps in alphabetic order, from Step A to Step B, etc.

F1 Part No. Each part is labeled with its Part No.

BOLT INSERTION



Several steps in this manual involve inserting F4 Bolts into the groove of Aluminum profiles as a preparation for further installation. Diagrams above illustrate how to use such inserted bolts.

F4 BOLTS AND NUTS

Part No. F4 refers to both the bolt and the nut. In some steps only the bolt or the nut will be used and in other steps the whole set will be used. Check the specific Part List in each step.

SEALING

Sealing the greenhouse by applying glue or tapes between the polycarbonate sheets and aluminum profiles will keep insects out and provide better stability against wind.

Sealant and glue gun are not included.

PARTS

Identify all parts using the parts list on next page and labels on the parts.

Layout each part needed for a step before working on that step.

MAINTENANCE

Inspect the greenhouse periodically.



When the greenhouse needs cleaning, use a gentle detergent.

Please contact seller on your
account for help if have any
problem when assemble or miss
something, we will try our best to
help you solve the issue.





PARTS LIST

Part No.	Part	Qty.	Part No.	Part	Qty.	Part No.	Part	Qty.	Part No.	Part	Qty.
D1		1	4L+4R		2+2	B7		1	B81		10
D2		1	5		1	Part No. Part Qty.			F10		10
D3		2	6		1	P1		2	B11		6
D4		1	7		4	P2		1			
F1		8	8L+8R		2+2	P3		4			
Part No.	Part	Qty.	9		2	P4L		2			
W1		1	10L		1	P4R		2			
W2		2	10R		1	P5		1			
W3		1	12		5	P6		1			
W4		1	13		1	P7		1			
S8		1	14		1	P8		8			
S9		1	15		1	P9		7			
F2		4	16		4	P10		1			
F8		1	17L+17R		1+1	Part No. Part Qty.			F4		138
F9		1	18		1	F6		2			
Part No.	Part	Qty.	19		6	Part No. Part Qty.			F5		40
S5		2	20		6	B8		1			
S6L		2	22		4	B9		2			
S6R		2	23		4	B10		2			
S7		2	25L+25R		2+2	Part No. Part Qty.					
Part No.	Part	Qty.	26		4			1			
1		2	B3		6	S1		26			
2L+2R		2+2	B4		4	M5		1			
3		4	B5		4	M6		1			
F3		24	B6		2						
B2		18									


Assembling of Pre-fabricated Base



Two foundation options with pre-fabricated Base

<p>Option 1 Corner Stakes mounted into the soil</p> <div data-bbox="128 602 1047 1540"> <div> <div>○</div> <div>○</div> </div> <div>Easy and quick to install. Suitable to use in areas with less extreme weather</div> <div>  </div> </div>	<p>Option 2 Corner Stakes mounted into concrete</p> <div data-bbox="1050 602 1955 1540"> <div> <div>○</div> <div>○</div> </div> <div>Best option if you want your greenhouse fully secured.</div> <div>  </div> </div>
<p>B</p> <p>Notice: If you choose option 2, the base can only be secured to the concrete floor after the greenhouse is fully assembled and attached to the base.</p> <p>Take the fully assembled greenhouse with base to the chosen site. Detach B2 and the screw, but keep the greenhouse on the base. Attach B2, B81 and the screw to the bolt. Secure base to the concrete floor with F10.</p>	<p>Warning:</p> <p>When choosing which B2 to detach, avoid the B2 on 7.</p>
	

1. Assembling of Door



Part No.	Part	Qty.
D1		1
D2		1
D3		2
D4		1
F1		8
P1		2

OUTSIDE VIEW



1. Assembling of Door Continued

<p>A</p>	<p>B</p>	<p>C</p>
<p>D</p> <p>Insert P1 into the grooves of D1, D2, and D3. Direction: Right to Left.</p>	<p>E</p> <p>Insert P1 into the grooves of D1, D3, and D3. Direction: Right to Left.</p>	<p>F</p>
<p>G</p>	<p>H</p>	<p>Notice:</p> <ol style="list-style-type: none"> 1. D1 and D4 are not interchangeable. 2. Note the orientation of D3


2. Assembling of Roof Vent

Part No.	Part	Qty.
W1		1
W2		2
W3		1
W4		1
S8		1
S9		1
F2		4
F8		1
F9		1
P2		1


INSIDE VIEW
















2. Assembling of Roof Vent Continued





INSIDE VIEW




3. Assembling of Main Frame

Part No.	Part	Qty
4L		2
4R		2
5		1
6		1
8L		2
8R		2
17L		1
17R		1
F4		48
F5		40
B8		1
B9		2
B10		2




3. Assembling of Main Frame Continued



Notice


For better visibility, the front wall and backwall shown from the second part of step 3 to step 6 have been distorted and thus look wider than the side walls. In reality, the side walls are wider.

3. Assembling of Main Frame Continued



OUTSIDE VIEW
Front(Door)



Part No.	Part	Qty.
4		2
5		1
6		1
7		4
10L		1
10R		1
F4		20





Repeat two times

Notice: 1. Nuts face inside.
2. Fasten these two nuts.

3. Assembling of Main Frame Continued



3. Assembling of Main Frame Continued



3. About step E, note that each 7 has two grooves where F4 bolts will be inserted into. The groove facing either side wall of the greenhouse is groove a, and the one facing either the door or the back wall is groove b. In step E, insert 2 Bolt F4 into each groove b, and one Bolt F4 into each groove a.







Part No.	Part	Qty.
12		2
15		1
F4		6
S1		6
P5		1
P6		1
P4L		1
P4R		1
P3		2

The assembly diagram illustrates the construction of a three-panel display stand. The main components are labeled as follows:



- Base (6):** The bottom horizontal support bar.
- Support (5):** The vertical support bars.
- Back Panels:** P3 (bottom), P4L (left), P4R (right), P5 (center), and P6 (top).
- Assembly Points:** Indicated by callouts A through M, showing where parts are joined using bolts (F4) and brackets (S1).


OUTSIDE VIEW
Front(Door)

4. Assembling of Backwall Continued

<p>A</p>  <p>F4*2</p> <p>12</p> <p>Repeat two times</p>	<p>B</p>  <p>F4*2</p> <p>15</p>	<p>C</p> <p>Insert P3 into grooves of 7, 10L till P3 rests on 5.</p>
<p>D</p> <p>Insert P5 into grooves of 10L, 10R till P5 rests on 5.</p>	<p>E</p> <p>Insert P3 into grooves of 10R, 7 till P3 rests on 5.</p>	<p>F</p>  <p>12</p> <p>P3</p>
<p>G</p>  <p>15</p> <p>P5</p>	<p>H</p>  <p>12</p> <p>P3</p>	<p>I</p> <p>Insert P4R into grooves of 7, 10L till P4R goes into the top groove of 12.</p>
<p>J</p> <p>Insert P6 into grooves of 10L, 10R till P6 goes into the top groove of 15.</p> <p>K</p> <p>Insert P4L into grooves of 10R, 7 till P4L goes into the top groove of 12.</p>	<p>M</p>  <p>P5 P3</p> <p>S1</p> <p>5</p>	<p>Notice</p> <p>Have a person buttress the back wall.</p>





4. Assembling of Backwall Continued

Part No.	Part	Qty.
F4		10
14		1






OUTSIDE VIEW
Front(Door)

4. Assembling of Backwall Continued



<p>A</p> 	<p>B</p> 
<p>C</p> 	<p>D</p> 
<p>Notice 1</p> <p>1. About Step A or D, two Bolt F4 will be used. One comes from 7 and the other from 12. Both of these two bolts were inserted into respective grooves in previous steps. You do not need new bolts here, only the nuts.</p> <p>2. Fasten the nuts.</p>	<p>Notice 2</p> <p>1. About Step B or C, three Bolt F4 will be used. One from 12, one comes from 10L/10R, and the rest from 15. All of these bolts were inserted into respective grooves in previous steps. You do not need new bolts here, only the nuts.</p> <p>2. Fasten the nuts.</p>



5. Assembling of Front wall

Part No.	Part	Qty.
9		2
F4		6




5. Assembling of Front wall
Continued








Part No.	Part	Qty.
13		1
F4		2




- Notice**
- 1. About Step B, only insert **Bolt F4** into the groove. Do not screw the nut.
 - 2. About Step C, one **Bolt F4** will be used. It comes from **9** and was inserted into **9** in Step B. You do not need new bolts here, only the nuts.
 - 3. Note the orientation of **13**.
 - 4. Notice that in step A and B, **9** has one of its end removed. The removed space is where **13** is rested.

5. Assembling of Front wall
Continued






Part No.	Part	Qty.
12		2
P3		2
P4R		1
P4L		1
P7		1
F4		4
S1		4






OUTSIDE VIEW
Back

5. Assembling of Front wall Continued


<p>A</p>  <p>F4*2</p> <p>12 Only insert the bolts. Do not screw the nuts. Repeat two times</p>	<p>B</p> <p>Insert P3 into grooves of 7 and 9 till P3 rests on 6.</p> <p>Repeat two times</p>
<p>C</p>  <p>12</p> <p>P3</p> <p>Repeat two times</p>	<p>D</p> <p>Insert P4R into grooves of 7 and 9, till P4R goes into the top groove of 12.</p>
<p>E</p> <p>Insert P4L into grooves of 7 and 9, till P4L goes into the top groove of 12.</p> <p>F</p> <p>Insert P7 into the top groove of 13.</p> <p>Have a person or a chair to buttress the front wall.</p>	 <p>P4L</p> <p>12</p> <p>P3</p> <p>S1</p> <p>6</p>

5. Assembling of Front wall Continued



Part No.	Part	Qty.
B3		4
F4		4




OUTSIDE VIEW
Back




6. Assembling of Roof Frames


Part No.	Part	Qty.
8(8L+8R)		2
F4		4




6. Assembling of Roof Frames Continued




6. Assembling of Roof Frames Continued


Part No.	Part	Qty.
16		4




6. Assembling of Roof Frames Continued




6. Assembling of Roof Frames Continued

Part No.	Part	Qty.
F4		8




OUTSIDE VIEW
Front



Notice

Note that **16** has two grooves, **groove a** on the upper side, and **groove b** on the lower side.





6. Assembling of Roof Frames Continued




Notice


1. Only insert the bolt. Do not screw the nut.

7. Securing of Frames

Part No.	Part	Qty.
17(17R+17R)		1
B4		2
F4		6
F6		2




7. Securing of Frames Continued




Part No.	Part	Qty.
B4		2
F4		8
B6		2
B5		4
F4		24
18		1
Roof Vent		1

7. Securing of Frames Continued



OUTSIDE VIEW
Front







Notice



1. Four **Bolt F4** will be used in **step A**. They are inserted into the lower groove of **16** in this very step.
2. Note how **B5** and the bolts are connected.
3. Fasten the nuts
4. Repeat four times.

8 is rendered invisible in this diagram for better visibility..

7. Securing of Frames Continued


<p>B</p>  <p>Inside View</p>	<p>Notice</p> <ol style="list-style-type: none"> 1. Four Bolt F4 will be used in step B. They are inserted into the lower groove of 16 in this very step. 2. Note how B6 and the bolts are connected. 3. Fasten the nuts 4. Repeat two times. <p>17 is rendered invisible in this diagram for better visibility..</p>
<p>C</p>  <p>Inside View</p>	<p>D</p>  <p>Inside View</p>
<p>Notice</p> <ol style="list-style-type: none"> 1. In step C and D, each step utilizes 4 Bolt F4. F4a and F4b were inserted into the upper groove of 16 in previous steps. F4c and F4d were inserted into the groove of 10L or 10R. 	<p>E-1</p>  <p>Outside Profile View</p>

7. Securing of Frames Continued









Notice

About Step F, slide the **roof vent** into the **left track** of **17**. Position of the roof vent will be adjusted later.



8. Assembling of Middle Frame

Part No.	Part	Qty.
19		6
20		6
F4		6



8. Assembling of Middle Frame Continued

A-1

Slide **19** to the position shown on previous page. The head of the Bolt **F4** on **8** and **4** should go into the groove of **19**.

A-2

Insert three **F4** inside the groove of **19**. You will notice two **F4**'s heads on **8** and **4**. Insert the two heads into the groove of **19** and make sure the three **F4** are caught in the middle. Fasten the two **F4** on **8** and **4**. Do this step for all the six **19**.



INSIDE VIEW

B


Insert three **F4** inside the groove of **20**. You will notice two **F4**'s heads on **8** and **17**. Insert the two heads into the groove of **20** and make sure the three **F4** are caught in the middle. Fasten the two **F4** on **8** and **4**. Only do this step for the two **20** on the left.





INSIDE VIEW

C


Insert two **F4** inside the groove of **20**. You will notice two **F4**'s heads on **8** and **17**. Insert the two heads into the groove of **20** and make sure the three **F4** are caught in the middle. Fasten the two **F4** on **8** and **4**. Do this step for the two **20** on the left and four **20** on the right.



9. Assembling of Roof Vent Holder



Screw on the nut of **Bolt F4** but do not fasten it.



Screw on the nuts of **Bolt F4** but do not fasten them.

9. Assembling of Roof Vent Holder Continued

C-1


Place the newly assembled 12 next to the roof vent. Note that the three pointers of B7 must face toward the ridge.

Locate two previously inserted **F4 Bolts**, in the groove of **20**

Adjust the position of two **B3** assembled to **12** in **Step A** to a position so that the two **F4 Bolts** found in **Step C-1** go through the holes of **B3**.


C-2

Fasten the four F4 on two B3 with nuts. Notice that after C-2 is done, there are two F4 that can move freely inside the two F4 on the left that are next to the vent.



How to use the Roof Vent-1

Roof Vent




Roof Vent

W4




20

B7

Note that B7's position decides the opening height of the roof vent. Fasten the nuts on B7 when you are satisfied with the opening.



10. Assembling of Side Braces




D-1

Inside View

Inside View
D-2

Step D-1 and D-2

This step utilizes two previously inserted **F4 Bolts**, one in the groove of **9** (or **10L/10R** for the backwall), the other in the groove of **7**.

Slide these two bolts to the position shown on the diagrams above and place **22** under the bolts. Fasten the nuts.

10. Assembling of Side Braces Continued


E

**Inside View
SIDE WALL**


Step E-1 and E-2


This step utilizes two previously inserted **F4 Bolts**, one in the groove of **19** the other in the groove of **7**.





Slide these two bolts to the position shown on the diagrams on previous page and place **23** under the bolts. Fasten the nuts.

11. Assembling of Panels





- A**
Insert Panel **P8**.
- B**
Insert Panel **P9**.
- C**
Insert Panel **P10**.




Part No.	Part	Qty.
P8		8
P9		7
P10		1
S1		16

Polycarbonate Panel Layout


Back



Left









OUTSIDE VIEW




Front

12. Assembling of Gutters and Caps


Part No.	Part	Qty.
25(25L+25R)		2
S5		2
S6L		2
S6R		2
S7		2




12. Assembling of Gutters and Caps Continued



13. Assembling of Horizontal Braces






Part No.	Part	Qty.
F4		10
26		4




Use the free F4 in 7 and the lower F4 in 19 to connect the brace 26 to the side wall.
After this step is done, you will still have one F4 in each 19.


13. Assembling of Horizontal Braces




Part No.	Part	Qty.
F4		10
26		4



Notice 1
The bolt comes from 7, which was inserted into the groove of 7 in previous step. You do not need new bolts.






Notice 2
The bolt comes from 19, which was inserted into the groove of 19 in previous step. You do not need new bolts.




Notice 2
Two 26 over lap.
The bolt comes from 19, which was inserted into the groove of 19 in previous step. You do not need new bolts.

14. Assembling of Horizontal Braces




Part No.	Part	Qty.
F4		12
B11		6


14. Reinforcing the Frame With Small Braces




Notice 1
We will use 9 smaller braces B11 to improve the overall stability of the greenhouse. Use six B11 to connect 19 and 20, and three B11 to connect two 20. The left F4 in the groove of 19 and 20 are for this step. Fasten the F4 with nuts.

Securing the greenhouse to the prefabricated Base



Part No.	Part	Qty.
B2		18

Securing the greenhouse to the prefabricated Base Continued



A

Get inside the greenhouse and locate all the **F4 Bolts** on **4**, **5**, and **6**.

Unscrew the nuts.

Attach **B2** to the bolt, fasten the nut to secure the greenhouse to the base.

There are 18 **F4 Bolts**.

